

---


# Desk Docking

## Quick Start Guide

### Content

- Desk Docking x 1
- Quick Start Guide x 1
- Docking Driver CD x 1

### Specification



1. 12-19 DC IN
2. USB 2.0 x 2 (with 5V / 1A)
3. LAN (10/100)
4. VGA output
5. RS232 (with 12V / 1A)

### First Time Operation

#### **Driver installation**

For the tablet to work with the desk docking, the driver for the desk docking has to be installed first. The desk docking driver is not pre-installed on the tablet. For a detail installation guide, please refer to the CD that is included with the package OR visit winmate official site's download center to download the latest driver: <http://www.winmate.com.tw/>

---

## **How to Use**

### **Insert Tablet**

1. Align the docking alignment fingers on the bottom of the desk docking mount to the bottom of the tablet where the two alignment holes are, then lower the tablet in to position.
2. Make sure the tablet is aligned with the desk docking. Reposition if the tablet still moves around.

### **Remove Tablet**

1. Remove the tablet by lifting the tablet straight up from the desk docking.

### **Powering the Desk Docking**

The desk docking's input/output expansion functions will only work if power is connected. Use the power adapter included with the tablet (the desk docking does not come with a separate power adapter).

## **External Display Modes**

Display Modes	Description
<b>Mirror Mode (Default)</b>	Under mirror mode, users can easily operate with touch screen.
<b>Extend Mode</b>	It is recommend to operate the tablet with keyboard / mouse under this mode. If touch function is desired, please use the mirror mode.

Note: Display settings are saved automatically for use next time.